Remote Control

PACKAGE INCLUDES:

- Remote Control ... 1PC

BATTERY REPLACEMENT:

- Slide off the back cover to replace the CR2032 battery. Follow the polarity instructions.
- Press any button on the Remote Control. The red LED will light if the battery is installed correctly.

HOW TO LEARN CODE WITH YOUR WIRELESS DOOR ALARM W/REMOTE'S MAIN UNIT :

- Slide down the battery cover of the Main Unit, and press the small button beside the battery compartment once. A beep will sound, and the red LED will flash for 5 seconds. The Main Unit is now waiting for the Remote Control to learn the code.
- Press any button on the Remote Control and you'll hear a Bi-Bi sound. This indicates the code has been learned successfully.

HOW TO ARM/DISARM YOUR WIRELESS DOOR ALARM W/REMOTE'S MAIN UNIT:

- Press the ON button on the Remote Control, a Beep will sound, and the Main Unit will be armed in three seconds. The red LED will flash three times.
- Press the OFF button on the Remote Control, a Bi-Bi will sound, accompanied by a flashing red LED. The device is now disarmed.
- Under ARM status, once the door is opened, the alarm will go off continuously for 30 seconds.
- Turn off the alarm by pressing the OFF button on the Remote Control or slide the switch to OFF on the Main Unit.